

Safety

1. To prevent possible hearing damage, do not listen at high volume levels for long periods.

Warranty

Porta Phone Co. items are warrantied against defects in material and/or factory workmanship for a set period from the date of purchase. Standard repairs due to misuse or wear and tear, as well as replacement parts including but not limited to batteries, padding, USB cable, etc. are excluded. Shipping to Porta Phone Co. is at customer's expense, Porta Phone Co. will pay for return ground shipping if the product warranty applies to the repair. Call for details.

Shipping

Prior to returning your headset for warranty or service you must call Porta Phone Co. for an RA (return authorization) number: 1.800.233.1113.

General Service

All repair work will be performed for the cost of replacement parts and return shipping from the Porta Phone factory.

Service / Porta Phone Co.
145 Dean Knauss Drive
Narragansett, RI. 02882

www.portaphone.com


1.800.233.1113



The T1

Wireless Earbud Headsets

T1 Earbuds with Wireless Pairing



Power ON: Remove earbuds from charging box.
Power OFF: Place earbuds into charging box.

A	Charging Contacts
B	LED Indicator
C	Smart Touch Control – Volume button
D	Ear-hook – Ergonomic design for athletes

Pairing

- 1) The T1 will seek wireless pairing automatically when removed from charging box.
- 2) LED flashing red & blue indicates search mode. Solid blue LED indicates pairing is successful.
- 3) Once paired (even if turned off), the T1 will automatically find the last connected device.

T1 Earbud Instructions

Headset Placement

To ensure proper fit place Earbuds in ear as marked (L=left & R=right).



Additional winged earmuffs Included for smaller ears. (To remove earmuffs, turn counter-clockwise 360° and pull. New Earmuffs snap on.)



Adjust volume via Smart Touch Controls (C).
Long press “Right” earbud touch area = Volume UP
Long press “Left” earbud touch area = Volume DOWN.

Charging

Place T1 into case with adjustable rubber earbuds rotated to the up or down position (Note: Straight position may cause insufficient contact).



Plug USB A-Type into power source, micro USB into charging box.

Red = Charging,
Green = Complete.

Charging time 1.5 hours
Supports up to 8 hours of usage.

