

## Safety

- 1) To prevent possible hearing damage, do not listen at high volume levels for long periods.
- 2) Risk of explosion if battery is replaced by an incorrect type, dispose of battery according to the instruction.
- 3) Recycle your products. The WEEE logo appears on the product to indicate that this product must not be disposed of or dumped with your other household wastes. You are liable to dispose of all your electronic or electrical waste equipment by transporting to an appropriate collection point for recycling of such hazardous waste.
- 4) FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.
- 5) IC Warning: This device complies with Industry Canada license-exempt RSS standards. Operation is subject to the following two conditions: 1. This device may not cause interference, and 2. This device must accept any interference including interference that may cause undesired operation of the device.
- 6) IC Radiation Exposure Statement: This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.
- 7) FCC Notice: This device complies with Part 15 of FCC rules. Operation is subject to the following 2 conditions: 1. This device may not cause harmful interference, and 2. This device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## Warranty

Porta Phone items are warranted against defects in material and/or factory workmanship for a set period from the date of purchase. Standard repairs due to misuse or wear and tear, as well as replacement parts including but not limited to batteries, padding, USB cable, etc. are excluded. Shipping to Porta Phone is at customer's expense, Porta Phone will pay for return ground shipping if the product warranty applies to the repair. Call for details.

### Shipping

Prior to returning your headset for warranty or service you must call Porta Phone for an RA (return authorization) number: 1.800.233.1113.

### General Service

All repair work will be performed for the cost of replacement parts and return shipping from the Porta Phone factory.

Service / Porta Phone  
145 Dean Knauss Drive  
Narragansett, RI. 02882

www.portaphone.com  
1.800.233.1113



**MAXIMUM POWER OUTPUT!**

**WEAR MIC ON LEFT OR RIGHT**  
Mic boom swivels 270 degrees.

**LITHIUM BATTERIES**  
Provide continuous 6 hr operation and are field replaceable.

**SPREAD SPECTRUM**  
Operating System

# EVADE Wireless

## Single Channel Systems

## Instruction Manual





## IMPORTANT



Single Channel EVADE Systems  
include one Headsets labeled MAIN

*This MAIN headset must be turned ON to link the REMOTE headsets*

EVADE are powered by a Lithium Polymer battery  
that will operate 6 hours when fully charged.

### Charging

1. Batteries are charged via the multi-charger.
2. Insert the battery making sure contacts are properly aligned.



Each battery slot has a  
corresponding LED indicator  
RED – Charging  
GREEN – Fully Charged charger

### Installation

1. To eject battery press the release button located at the top of the compartment.
2. To insert battery snap into place.



### Low Indicator

A repetitive beep indicates low power – battery  
should be charged or replaced.

### Battery Care


To preserve optimum charge level remove battery from  
compartment when system is not in use.

## Operation

ON / OFF Power

### ON/OFF Power Button

1. Press the power button on the MAIN headset – flashing LED indicates Power is ON.
2. Press the power button on the REMOTE headset(s).
3. The LED on all headsets will flash & then Turn solid indicating headsets have linked.



Volume UP / DOWN

Note: to turn off, press and hold the power button for 2-3 sec.  
When LED turns red, release.

### Set Volume

EVADE feature five volume settings. Click UP or DOWN volume buttons. Audible tone will sound. Double tone indicates low or max volume.

## Microphone Placement

Position the microphone one finger  
width distance from mouth.

Speak into the front of the microphone,  
Indicated by the arrow & TALK.



## AutoMute Function

Boom swivels over The top 270 degrees.  
Headset can be worn On left or right.

Microphone mutes when boom is in UP position.

