

## BATTERY CHARGING

SYSTEM INCLUDES 2 COM-CENTER BATTERIES. One for the 1<sup>st</sup> half, and one for the 2<sup>nd</sup> half.

- 1) Plug AC adapter into charging base and wall outlet (note: the system includes two AC adapters, one for charger, one for Com-Center; they are NOT interchangeable).
- 2) Snap batteries into charging slot securely.
- 3) Charge time 2 – 4 hours. GREEN: fully charged; RED: charging; Flashing RED: faulty battery; NO LIGHT: battery improperly inserted.
- 4) COMSTAR high capacity lithium batteries provide up to 10 hours of operation.
- 5) Lithium batteries do not develop a memory - do not drain after use.



Charge up to 2 Com-Center batteries and up to 8 headset batteries.



## Safety

1. To prevent possible hearing damage, do not listen at high volume levels for long periods.
2. Risk of explosion if battery is replaced by an incorrect type, dispose of battery according to the instruction.
3. Recycle your products  
The WEEE logo (shown at right) appears on the product to indicate that this product must not be disposed of or dumped with your other household wastes. You are liable to dispose of all your electronic or electrical waste equipment by transporting to an appropriate collection point for recycling of such hazardous waste.



## FCC Notice

This device complies with Part 15 of FCC rules. Operation is subject to the following 2 conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Porta Phone Co Inc  
145 Dean Knauss Dr  
Narragansett RI 02882



[www.portaphone.com](http://www.portaphone.com)

1.800.233.1113

# All Wireless

User Manual

Full Duplex Wireless System



### IMPORTANT! LINE OF SIGHT:

For optimum range position the Com-Centers so that the radio signals have a clear path to the wireless headsets.

### COM-CENTER START

- 1) Attach AC power cord to each Com-Center, then plug into the nearest wall outlet.
- 2) If a wall outlet is not available insert rechargeable battery into slot at back of Com-Centers (silver contacts must be in proper position).
- 3) OR use five brand name AA batteries in battery sled (provided).
- 4) Plug interconnect cable into phone jacks at the back of each Com-Center, than place 4 to 5 feet apart.
- 5) Turn Com-Center ON (switch on back panel).
- 6) At start-up, system is Offense / Defense. Press CONFERENCE buttons to switch to All-Conference.



Compartment on unit bottom houses switches for factory programming. Call Porta Phone Co. for more information.

### ALL-IN-ONE SERIES START-UP

- 1) Insert battery into headset. Headset will automatically turn ON.



### BLUE LED INDICATIONS

- 1) Flashing blue LED on headset indicates automatic tuning to Com-Center signal.
- 2) When the Com-Center is ON the headset LED will change to solid blue – ready for communication.

### Operation

#### HEADSET CONTROLS

1) **POWER BUTTON** – After the battery is installed, the power button is used to turn the headset ON and OFF.

OFF by pressing and holding until LED goes out.

ON by quick clicking, LED illuminates.

Power

Volume

MIC Mute



2) **VOLUME** - Volume control buttons adjust to any of five settings.

3) **MIC Mute – Grey Button**

Click MIC button to mute microphone – audible tone confirms change.

4) **Channel Switch – Red Button**

Included with switching headsets. Change channels by quick-clicking channel button. Do not hold down.

Note: Repetitive beep indicates low battery.

### IMPORTANT TIPS

#### Microphone Placement

COMSTAR headsets include a special noise cancelling microphone. For optimum performance place directly in front of, and appx. 1 – 2 “ from mouth.



#### Rain Game / Storage

Place the Com-Center in a protected dry location during use. Before storing, wipe down all equipment and leave out in a well ventilated room to fully dry. Do not store in bags or carrying case when wet.